

Hydro TX145 Dark Matter

Dual layer top coat

- **Preparation**

- To apply products like these your vehicle must be in a temperature and humidity controlled environment during application and for at least 12 hours after.
- Wash and decontaminate your vehicle using an Iron remover, Tar remover and Mineral remover.
- Wipedown with IPA 1:1 before application if the car is in for just a top coat application. Do not use IPA when layering between base and top.

- **Application Hydro TX145**

- Apply 15-20 drops to your applicator and apply thick.
- Spread a puddle line then work in a cross-hatch pattern slowly.
- Size of the application area can be whole panels or work with the bodylines of the car.
- Wipe off with a new quality short pile microfiber until most is removed.
- Wipe off with a second short pile microfiber until all residue is removed.
- Buff with a new quality long pile microfiber.
- Once applied and removed carry out a final check with your long pile microfiber and a bright, but diffused light source. This will ensure no residue remains on the surface.
- Apply the second layer immediately after the first one.
- Apply Ultra 3.0 after 2 hours.
- Do not expose your vehicle to the elements for at least 10 hours.
- Do not wash for the first 14 days.

- **Additional**

- Two layers of Hydro back to back is on average 30ml.
- Reapply every 2 years.
- Change your applicator and microfibers as needed.
- Apply Ultra 3.0 every 3 months.