

Pyro Dark Matter

Single layer coating 2µm

- **Preparation**

- To apply products like these your vehicle must be in a temperature and humidity controlled environment during application and for at least 12 hours after application.
- Wash and decontaminate your wheels using an Iron remover and Mineral remover. Clay the wheels if needed to remove hard bonded contaminants.
- Wash the wheels in dish wash solution before wipedown.
- Wipedown using IPA 1:1.

- **Application**

- Apply a good amount to your applicator and apply thick. Work in small areas.
- Wipe off IMMEDIATELY with a new aggressive quality short pile microfiber until most is removed.
- Wipe off with a second short pile microfiber until all residue is removed.
- Buff with a new quality long pile microfiber.
- Once applied and removed carry out a final check with your long pile microfiber and a bright, but diffused light source. This will ensure no residue remains on the surface.
- IR cure at 70°C for 15 minutes.
- Apply Ultra 3.0 after 4 hours.
- Do not expose the coating to the elements for at least 12 hours.
- Do not wash for the first 14 days.
- Apply TX145 every 2 years for optimum performance.

Additional

- Apply Ultra 3.0 every 3 months.