

- **TRITONTX550**

- **Application**

- Apply 15-20 drops to your applicator and apply thick.
- Spread a puddle line then work in a criss-cross pattern slowly.
- Size of the application area should be 50x50cm.
- Wipe off with a new quality short pile microfiber until most is removed.
- Buff with a new quality long pile microfiber and remove any remaining residue.
- Once applied and removed carry out a final check with your long pile microfiber and a bright, but diffused light source. This will ensure no residue remains on the surface.
- Apply Ultra 3.0 afterwards.
- Do not expose to the elements for at least 12 hours.
- Do not wash for the first 14 days.