

TITAN[®] COATINGS

PX10™, VULCANTX155™ & HYDROTX145™
Base coat & Extreme performance Top Coat

- PX10™ single layer base coat.
- Wait two hours before application of VULCANTX155™.
- VULCANTX155™ is a double layer top coat.
- Apply the second layer of VULCANTX155™ two hours after the first one.
- Wait two hours before application of HYDROTX145™
- Apply the second layer of HYDROTX145™ immediately on top of the first layer.
- IR cure base only recommended
- Fully cured in 12 hours



PYRO™ PACKAGE

- Single layer of PYRO™ manually applied
- IR curing recommended
- 48 hours fully cured

PX10™ BASE PACKAGES

PX10™ standalone

Base coat

- Entry level
- PX10 single layer base coat.
- IR curing recommended
- 10 hours fully cured

PX10™ & HYDROTX145™

Base coat & Top coat

- PX10™ single layer base coat.
- Wait two hours before application of HYDROTX145™.
- Apply two layers of HYDROTX145™.
- Apply the second layer of HYDROTX145™ immediately on top of the first layer.
- IR cure base only recommended
- 10 hours fully cured.

PX10™ & VULCANTX155™

Base coat & Top coat

- PX10™ single layer base coat.
- Wait two hours before application of VULCANTX155™.
- VULCANTX155™ is a double layer top coat.
- Apply the second layer of VULCANTX155™ two hours after the first one.
- IR cure base only recommended
- 12 hours fully cured.

HYPERGLASS™ PACKAGE

- Up to three layers of HYPERGLASS™ on the windscreen. Minimum two layers recommended on the windscreen.
- If layering HYPERGLASS™, please wait 15 minutes.
- One layer of HYPERGLASS on side and top glass.
- 10 hours fully cured
- Use a clay bar to decon every six months.